


TEMPLATE FOR UNDERMOUNT 3mm (1/8") OVERHANG INSTALLATION  
GABARIT POUR INSTALLATION SURPLOMBANT 3mm (1/8 ") SOUS-PLAN




OVERHANG INSTALLATION  
INSTALLATION SURPLOMBANT

NOTES

\*\*\*IMPORTANT\*\*\*  
Prior to cutting countertop, please ensure that templates dimensions correspond with actual countertop dimensions.  
Procedel is not responsible for any errors resulting from template provided.

\*\*\*IMPORTANT\*\*\*  
Avant la découpe du comptoir, veuillez vous assurer que les dimensions réelles sur le comptoir correspondent aux dimensions du gabarit.  
Procedel ne s'engage de toute erreur pouvant résulter des gabarits fournis.

TEMPLATE NO. / NO. GABARIT  
991001942  
PRODUCT NO. / NO. PRODUIT



RECOMMENDED INSTALLATION  
INSTALLATION RECOMMANDÉE

REV	BY	DESCRIPTION	DATE	DRAWN, T10	DATE: 2019-05-07

IHO-US-14148  
PRO  
CHEF

www.prochef.ca  
TEL.: 1-855-687-4912  
FAX.: 1-855-687-4293